


Nailbase 2-Ci

An easy to use 2-in-one bracing and continuous insulation board.

ThermaFoam R-Control Nailbase 2-Ci is the ideal two-in-one continuous insulation (Ci) sheathing board. ThermaFoam R-Control Nailbase 2-Ci consists of the following 2 components:

- 7/16" exposure 1 rated Oriented Strand Board (OSB) to provide bracing
- ThermaFoam R-Control insulation exceptional insulation performance
- Saves labor with one-step installation
- Braces and insulates
- Saves energy - no thermal breaks
- No R-value loss or thermal drift
- 4x8, 4x9, 4x10 standard boards available

 Thickness	R-value ¹	
	75°F ²	40°F ³
1 5/16	4.0	4.2
1 11/16	5.4	5.7
2 3/8	8.1	8.6
3 1/16	10.7	11.5

¹ R-value units are °F·ft²·h/Btu.

² Recommended for design in WARM climates.

³ Recommended for design in COLD climates.

Proven to meet, or exceed, building codes.

ThermaFoam R-Control is manufactured under an industry leading quality control program monitored by UL and further recognized in UL Evaluation Report UL ER40338-01. ThermaFoam R-Control meets ASTM C578, "Standard Specification for Rigid, Cellular Polystyrene Thermal Insulation".



FOAM FACTS:

ThermaFoam R-Control Nailbase 2-Ci outperforms other Nailbase products.

- 2-Ci is bracing and insulation all in one
- Installs in one easy step
- Saves time and money
- No R-value loss or thermal drift
- ThermaFoam R-Control with borate treatment available to provide termite resistance

Energy Code Ci Requirements.

The use of continuous insulation is mandated by the 2012 International Energy Conservation Code (IECC). The IECC provides a prescriptive path for wall thermal insulation that includes the use of continuous insulation.

Walls, above grade			
Zone	IECC-2012 Prescriptive Ci R-value		
	Residential	Commercial	
	Wood-Framed Wall	Wood-Framed	
		All other	Group R
1	None	R-3.8 ¹	R-3.8 ¹
2	None	R-3.8 ¹	R-3.8 ¹
3	R-5 ¹	R-3.8 ¹	R-3.8 ¹
4 except Marine	R-5 ¹	R-3.8 ¹	R-3.8 ¹
5 and 4 Marine	R-5 ¹	R-3.8 ¹	R-7.5 ¹ R-3.8 ²
6	R-10 ¹ R-5 ²	R-7.5 ¹ R-3.8 ²	R-7.5 ¹ R-3.8 ²
7	R-10 ¹ R-5 ²	R-7.5 ¹ R-3.8 ²	R-7.5 ¹ R-3.8 ²
8	R-10 ¹ R-5 ²	R-10 ²	R-10 ²

¹ For use with R-13 cavity insulation
² For use with R-20 cavity insulation

Installation.

Installation shall be in strict accordance with published instructions, details, and drawings that are part of the contract documents for the project.

1. ThermaFoam R-Control Nailbase 2-Ci must be installed perpendicular to structurally sound wood framing members.

2. Mechanically fasten the 2-Ci with the OSB held against the framing members using pneumatic nail guns designed to send nails through the insulation and seat firmly against the OSB.

Note: Fastener spacing should be in compliance with the International Building Code (IBC) or International Residential Code (IRC) for 7/16" OSB used as bracing over structural wood framing members.


3. Install weather resistive barriers and wall cladding materials per wall cladding manufacturer's specifications and recommendations for installation over continuous insulation.

Note: Climate conditions, code requirements, and building science dictate the use and position of vapor retarders within wall assemblies. Consult with local code officials and building science professional concerning the use of vapor retarders.

Ready to take control? Start here.

If you're ready to have ThermaFoam R-Control contribute to your next project, just contact your ThermaFoam R-Control, Inc. Technical Sales Representative. They will be happy to give you design consultation, information about ThermaFoam R-Control products, pricing, and answers to all of your questions.

NEED INFORMATION OR A QUOTE



sales@thermafoam.com | www.thermafoam.com



**1240 Hwy 77
Hillsboro, TX 76645**

**Office: 254-582-2730
Fax: 254-582-2811**